

INSTRUCTIONS FOR YOUR NEW ESPON LABELWORKS PX PRINTER.

Label Editor Professional Software and Drivers for Epson LABELWORKS PX.

A CD-ROM is no longer included with your printer. You need to go to the manufacturer's site and download.

DOWNLOAD LINK: labelworks.epson.com/downloads/

*****DO NOT DOWNLOAD VERSION 2.02 SCROLL DOWN ON THE PAGE AND LOOK FOR VERSION 1.3***, it's zipped**

***** MAC USERS SCROLL PASS THE 1.3 AND LOAD THE LABEL EDITOR LITE SOFTWARE***, it's zipped**

Label Editor Professional is compatible with Windows® PC operating systems: Windows® Vista, ® 7 (32/64 bit),
® 8.1, 8 (32/64 bit) or Windows® 10 (32/64bit)

****IMPORTANT - KEEP USB UNPLUGGED****

If you have a LABELWORKS LW-PX400, LW-PX700, LW-PX750, LW-PX900 or LW-PX800 (non-network) follow these instructions:

You need to extract (unzip) by double clicking the folder, then choose setup. Install the software. Then there is a pause. The driver install begins. Choose the appropriate printer model. When instructed, plug in the USB and press the **ON** power button on the printer. Driver install will complete. Wait for the green check mark. You'll be good to go.

**IF YOU HAVE ANY QUESTIONS, CALL LARRY @ LRT GROUP, INC. 954-384-7656 or
CALL EPSON – LABELWORKS PX, @ 800-622-6312 Ext. 0**